



Lenovo G70-80 Battery Replacement

This is a replacement guide for the Lenovo G70-80 battery.

Written By: Alexis Buford



INTRODUCTION

We plan to teach you how to remove and replace the battery on your Lenovo G70-80.

Step 1 — Battery



- Turn off the computer.
- Set the computer upside down with the back facing up.

Step 2



- ① Located directly below the back plate will be two switches near where the battery is located.
- With the battery facing you, slide the battery switch on the right side of the laptop towards the right.
- ① Once it is unlocked, you will see a red indicator next to the switch.

Step 3



- i** After the switch on the right is unlocked, you will hear a click, and you should see a red indicator next to the switch.
- Slide the left battery release switch to the left.
 - While holding the switch to the left, lift the battery.

Step 4



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-06 01:09:08 AM.